Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking Label	ID	Description/Gu
	Colour Code Legend									dance
	field name in yellow = required field name in purple = recommended					IMPORTANT: Only labels deprecated, always with re				
	field name in white = optional					provided. If a term change				
	'					term will be created.				
ample collection and processing		GENEPIO:0001150		The sample ID should represent the identifier	ABCD123					
				assigned to the sample at time of collection,	ADCD 123					
				for which all the descriptive information applies. If the original sample ID is unknown						
		GENEPIO:0001123	The user-defined name for the	or cannot be provided, leave blank or provide				3.0.0	3.0.0	200
ample collection and processing	sample_collector_sample_ID	GENEPIO:0001123	sample.	a null value.  Alternative identifiers assigned to the sample	ABCD1234[PHAC];			3.0.0	3.0.0	3.0.0
				should be tracked along with original IDs to establish chain of custody. Alternative sample IDs should be provided in the in a prescribed format which consists of the ID followed by square brackets (no space in between the ID and bracket) containing the short form of ID provider's agency name i.e. ID[short organization code]. Agency short forms	12345rev[CFIA]					
				include the following: Public Health Agency of Canada: PHAC Canadian Food Inspection Agency: CFIA Agriculture and Agri-Food Canada: AAFC Fisheries and Oceans Canada: DFO Environment and Climate Change Canada: ECCC Health Canada: HC						
sample collection and processing	alternative_sample_ID	GENEPIO:0100427	An alternative sample_ID assigned to the sample by another organization.	Multiple identifiers can be provided and separated by semi-colons. If the information is unknown or cannot be provided, leave blank or provide a null value.				3.0.0	3.0.0	3.0.0
			The name of the organization with which the sample collector is	Provide the name of the agency, organization or institution that collected the sample in full (avoid abbreviations). If the information is unknown or cannot be provided, leave blank o	Canada (PHAC) [GENEPIO:0100551]					
ample collection and processing	sample_collected_by	GENEPIO:0001153	affiliated.	provide a null value.				3.0.0	3.0.0	3.0.0
				Provide the name of the specific laboratory that collected the sample (avoid abbreviations). If the information is unknown or cannot be provided, leave blank or provide a	Topp Lab					
Sample collection and processing	sample_collected_by_laboratory_name	GENEPIO:0100428	of the sample collector.	null value.  Provide the name of the project and/or the	Watershed Project (HA-120)			3.0.0	3.0.0	3.0.0
			The name of the project/initiative/program for	project ID here. If the information is unknown or cannot be provided, leave blank or provide	Watershed Project (PA-120)					
ample collection and processing	sample_collection_project_name	GENEPIO:0100429	which the sample was collected.	a null value.  Provide the name of the sample plan used for	National Microbiological			3.0.0	3.0.0	3.0.0
sample collection and processing	sample_plan_name	GENEPIO:0100430	The name of the study design for a surveillance project.	sample collection. If the information is unknown or cannot be provided, leave blank or provide a null value.	Baseline Study in Broiler			3.0.0	3.0.0	3.0.0
			, ,	Provide the identifier of the sample plan used for sample collection. If the information is unknown or cannot be provided, leave blank o	_					
ample collection and processing	sample_plan_ID	GENEPIO:0100431	for a surveillance project.	provide a null value.	'			3.0.0	3.0.0	3.0.0
sample collection and processing	sample_collector_contact_name	GENEPIO:0100432	The name or job title of the contact responsible for follow-up regarding the sample.	Provide the name of an individual or their job title. As personnel turnover may render the contact's name obsolete, it is more preferable to provide a job title for ensuring accuracy of information and institutional memory. If the information is unknown or cannot be provided, leave blank or provide a null value.	Enterics Lab Manager			3.0.0	3.0.0	3.0.0
, ,				Provide the email associated with the listed contact. As personnel turnover may render an individual's email obsolet, it is more preferable to provide an address for a position or lab, to ensure accuracy of information and institutional memory. If the information is						
		OENERIO 000445-	responsible for follow-up	unknown or cannot be provided, leave blank or	r					
ample collection and processing	sample_collector_contact_email	GENEPIO:0001156	regarding the sample.	provide a null value.  The reason a sample was collected may provide information about potential biases in sampling strategy. Provide the purpose of sampling from the picklist in the template. Most likely, the sample was collected for Diagnostic testing. The reason why a sample was originally collected may differ from the	Surveillance [GENEPIO:0100004]			3.0.0	3.0.0	3.0.0
Sample collection and processing	purpose_of_sampling	GENEPIO:0001198	The reason that the sample was collected.	reason why it was selected for sequencing, which should be indicated in the "purpose of sequencing" field.				3.0.0	3.0.0	3.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking Label	ID	Description/G
	Colour Code Legend							Label	טו	dance
Sample collection and processing	presampling_activity	GENEPIO:0100433	The activities or variables introduced upstream of sample collection that may affect the sample collected.	If there was presampling activity that would affect the sample prior to collection (this is different than sample processing which happens after the sample is collected), provide the experimental activities by selecting one or more values from the template pick list. If the information is unknown or cannot be provided, leave blank or provide a null value.	Antimicrobial pre-treatment [GENEPIO:0100537]			3.0.0	3.0.0	3.0.0
			The details of the activities or variables introduced upstream of sample collection that may affect	Briefly describe the presampling activity details	Chicken feed containing X amount of novobiocin was fed					
Sample collection and processing	presampling_activity_details	GENEPIO:0100434	the sample collected.	using free text.	to collection of litter.			3.0.0	3.0.0	3.0.0
Comple collection and processing	experimental _protocol_field	GENEPIO:0101029	The name of the overarching experimental methodology that was used to process the biomaterial	Provide the name of the methodology used in your study. If available, provide a link to the protocol.	OneHealth2024_protocol			11.1.1	11.1.1	11.1.1
Sample collection and processing	experimental_specimen_role_type	GENEPIO:0100921	The type of role that the sample represents in the experiment.	Samples can play different types of roles in experiments. A sample under study in one experiment may act as a control or be a	Positive experimental control [GENEPIO:0101018]			11.1.1	11.1.1	11.1.1
Sample collection and processing			The processing applied to samples post-collection, prior to	experiment may act as a control of be a replicate of another sample in another. Provide the sample processing information by selecting a value from the template pick list. If	Samples pooled [OBI:0600016]			11.1.1	11.1.1	11.1.1
Sample collection and processing	specimen processing	GENEPIO:0100435	further testing, characterization, or isolation procedures.	the information is unknown or cannot be provided, leave blank or provide a null value.				3.0.0	3.0.0	3.0.0
Sample collection and processing	specimen processing details	GENEPIO:0100435	The details of the processing applied to the sample during or after receiving the sample.	Briefly describe the processes applied to the sample.	25 samples were pooled and further prepared as a single sample during library prep.			13.3.3	13.3.3	13.3.3
Sample collection and processing	nucleic acid extraction method	GENEPIO:0100939	The process used to extract genomic material from a sample.	Briefly describe the extraction method used.	Direct wastewater RNA capture and purification via the "Sewage, Salt, Silica and Salmonella (4S)" method v4			11.1.1	11.1.1	11.1.1
sample concessor and processing	nucleic acid extraction kit	GENEPIO:0100772	The kit used to extract genomic material from a sample	Provide the name of the genomic extraction kit used.	found at QIAamp PowerFecal Pro DNA Kit			11.1.1		11.1.1
Sample collection and processing								11.1.1	11.1.1	11.1.1
Sample collection and processing	geo_loc_name (country)	GENEPIO:0001181	The country of origin of the sample.	Provide the name of the country where the sample was collected. Use the controlled vocabulary provided in the template pick list. If the information is unknown or cannot be provided, provide a null value.	Canada [GAZ:00002560]			3.0.0	3.0.0	3.0.0
Sample collection and processing	geo_loc_name (state/province/region)	GENEPIO:0001185	The state/province/territory of origin of the sample.	Provide the name of the province/state/region where the sample was collected. If the information is unknown or cannot be provided, provide a null value.	British Columbia [GAZ:00002562]			3.0.0	3.0.0	3.0.0
Sample collection and processing	geo_loc_name (site)	GENEPIO:0100436	The name of a specific	Provide a hair value.  Provide the name of the specific geographical site using a specific noun (a word that names a certain place, thing).	Credit River			3.0.0	3.0.0	3.0.0
			The country of origin of a food	If a food product was sampled and the food product was manufactured outside of Canada, provide the name of the country where the food product originated by selecting a value from the template pick list. If the information is unknown or cannot be provided, leave blank or						
Sample collection and processing	food_product_origin geo_loc_name (country)		product.	provide a null value.  If a sample is from a human or animal host that originated from outside of Canada, provide the the name of the country where the host originated by selecting a value from the template pick list. If the information is unknown or cannot be provided, leave blank or provide	South Africa [GAZ:00001094]			3.0.0	3.0.0	3.0.0
Sample collection and processing	host_origin geo_loc_name (country)	GENEPIO:0100438	The country of origin of the host.	a null value.				3.0.0	3.0.0	3.0.0
				If known, provide the degrees latitude. Do NOT simply provide latitude of the institution if this is not where the sample was collected, nor the centre of the city/region where the sample	38.98 N					
			The latitude coordinates of the	was collected as this falsely implicates an existing geographical location and creates data inaccuracies. If the information is						

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking Label	ID	Description/Gui
	Colour Code Legend			NOT simply provide longitude of the institution	77.11 W			Label		dance
			The longitude coordinates of the	if this is not where the sample was collected, nor the centre of the city/region where the sample was collected as this falsely implicates an existing geographical location and creates data inaccuracies. If the information is						
Sample collection and processing	geo_loc longitude	GENEPIO:0100310	geographical location of sample collection.	unknown or cannot be provided, leave blank or provide a null value.	7			3.0.0	3.0.0	3.0.0
Sample collection and processing	sample_collection_date	GENEPIO:0001174	The date on which the sample was collected.	Provide the date according to the ISO 8601 standard "YYYY-MM-DD", "YYYY-MM" or "YYYY".	2020-10-30			3.0.0	3.0.0	3.0.0
			The precision to which the "sample collection date" was	Provide the precision of granularity to the "day", "month", or "year" for the date provided in the "sample collection date" field. The "sample collection date" will be truncated to the precision specified upon export, "day" for "YYYY-MM-DD", "month" for "YYYY-MM", or	day [UO:0000033]					
Sample collection and processing	sample_collection_date_precision	GENEPIO:0001177	The date on which sample	"year" for "YYYY".  Provide the date that sample collection ended	2020-03-18			7.6.4	7.6.4	7.6.4
Sample collection and processing	sample_collection_end_date	GENEPIO:0101071	sample.	in ISO 8601 format i.e. YYYY-MM-DD  Provide the sample processed date in ISO	2020-03-16			13.3.3	13.3.3	13.3.3
			The date on which the sample	8601 format, i.e. "YYYY-MM-DD". The sample may be collected and processed (e.g. filtered, extraction) on the same day, or on different	2020-03-10					
Sample collection and processing	sample_processing_date	GENEPIO:0100763	was processed. The time at which sample	dates.  Provide this time in ISO 8601 24hr format, in	17:15 PST			13.3.3	13.3.3	13.3.3
Sample collection and processing	sample_collection_start_time	GENEPIO:0101072	collection began.  The time at which sample		19:15 PST			13.3.3	13.3.3	13.3.3
Sample collection and processing	sample_collection_end_time	GENEPIO:0101073	The descriptive time of day	your local time.  If known, select a value from the pick list. The time of sample processing matters especially for grab samples, as fecal concentration in	Morning			13.3.3	13.3.3	13.3.3
Sample collection and processing	sample_collection_time_of_day	GENEPIO:0100765	during which the sample was collected.  The amount of time over which	wastewater fluctuates over the course of the day.	1900-01-03			13.3.3	13.3.3	13.3.3
Sample collection and processing	sample_collection_time_duration_value	GENEPIO:0100766	the sample was collected.  The units of the time duration	Provide the numerical value of time.	Hour			13.3.3	13.3.3	13.3.3
Sample collection and processing	sample_collection_time_duration_unit	GENEPIO:0100767	measurement of sample collection.	Provide the units from the pick list.				13.3.3	13.3.3	13.3.3
Sample collection and processing	sample_received_date	GENEPIO:0001179	The date on which the sample was received.	Provide the date according to the ISO 8601 standard "YYYY-MM-DD", "YYYY-MM" or "YYYY".	2020-11-15			3.0.0	3.0.0	3.0.0
			The existing around the existing	Provide the sample description provided by the original sample collector. The original description is useful as it may provide further	RTE Prosciutto from deli					
Sample collection and processing	original_sample_description	GENEPIO:0100439	The original sample description provided by the sample collector.	details, or can be used to clarify higher level classifications.	B # 4 4 4			3.0.0	3.0.0	3.0.0
Sample collection and processing	environmental site	GENEPIO:0001232	An environmental location may describe a site in the natural or built environment e.g. hospital, wet market, bat cave.	If applicable, select the standardized term and ontology ID for the environmental site from the picklist provided. Multiple values can be provided, separated by a semi-colon.				3.0.0	3.0.0	3.0.0
campa concutor and processing	Control and Laboratory	CHE 16.5507252	NOT THE ROY, DECOUNT.	This field should be used when a sample is taken from an environmental location inhabited by many individuals of a specific type, rather than describing a sample taken from one particular host. If applicable, provide the standardized term and entology ID for the animal or plant population name. The standardized term can be sourced from this look-up service:	Turkey [NCBITaxon:9103]			0.0.0	0.0.0	5.0.0
Sample collection and processing	animal_or_plant_population	GENEPIO:0100443	The type of animal or plant population inhabiting an area.	https://www.ebi.ac.uk/ols/ontologies/genepio. If not applicable, leave blank.	f			3.0.0	3.0.0	3.0.0
			A substance obtained from the natural or man-made environment e.g. soil, water, sewage, door handle, bed	If applicable, select the standardized term and ontology ID for the environmental material from the picklist provided. Multiple values can	[ENVO:00002001]; Broom					
Sample collection and processing	environmental_material	GENEPIO:0001223	handrail, face mask.  The material constituents that	be provided, separated by a semi-colon.  If applicable, describe the material	lead; plastic			3.0.0	3.0.0	3.0.0
Sample collection and processing	environmental_material_constituent	GENEPIO:0101197	comprise an environmental material e.g. a pipe that is lined with lead.	constituents for the environmental material.  Multiple values can be provided, separated by a semi-colon.	, ,,			12.2.2	12.2.2	12.2.2
			A substance obtained from an	An anatomical material is a substance taken from the body. If applicable, select the standardized term and ontology ID for the anatomical material from the picklist provided.	Tissue [UBERON:0000479]; Blood [UBERON:0000178]					
Sample collection and processing	anatomical_material	GENEPIO:0001211	anatomical part of an organism e.g. tissue, blood.	Multiple values can be provided, separated by a semi-colon.				3.0.0	3.0.0	3.0.0

3/4/2025

3

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking	ID	Description/C:
	Colour Code Legend							Label	U	Description/Gu dance
			A substance excreted/secreted from an organism e.g. feces,	A body product is a substance produced by the body but meant to be excreted/secreted (i.e. not part of the body). If applicable, select the standardized term and ontology ID for the body product from the picklist provided. Multiple values can be provided, separated by	Feces [UBERON:0001988]; Urine [UBERON:0001088]					
Sample collection and processing	body_product	GENEPIO:0001216	urine, sweat.	a semi-colon.				3.0.0	3.0.0	3.0.0
Sample collection and processing	anatomical_part	GENEPIO:0001214	An anatomical part of an organism e.g. oropharynx.	An anatomical part is a structure or location in the body. If applicable, select the standardized term and ontology ID for the anatomical material from the picklist provided. Multiple values can be provided, separated by a semi-colon.	Snout [UBERON:0006333]			3.0.0	3.0.0	3.0.0
		GENERIO 0400700	A 3D region in space without well-defined compartmental	This field captures more granular spatial information on a host anatomical part e.g. dorso-lateral region vs back. Select a term	Dorso-lateral region [BSPO:0000080]			704	70.4	
Sample collection and processing	anatomical_region	GENEPIO:0100700	boundaries.	from the picklist.  This field includes animal feed. If applicable,	Feather meal			7.6.4	7.6.4	7.6.4
Sample collection and processing	food_product	GENEPIO:0100444	A material consumed and digested for nutritional value or enjoyment.	rns leid includes anima recu. It applicable, select the standardized term and ontology ID for the anatomical material from the picklist provided. Multiple values can be provided, separated by a semi-colon.	[FOODON:00003927]; Bone meal [ENVO:02000054]; Chicken breast [FOODON:00002703]			3.0.0	3.0.0	3.0.0
Sample collection and processing	food weedood washed	GENEPIO:0100445	Any characteristic of the food product pertaining to its state, processing, or implications for consumers	Provide any characteristics of the food product including whether it has been cooked, processed, preserved, any known information about its state (e.g. raw, ready-to-eat), any known information about its containment (e.g. canned)	[FOODON:00002777];			3.0.0	300	3.0.0
Sample collection and processing	food_product_properties	GENEPIO.0100445	A claim made by the label that	Provide any characteristic of the food product,	Antibiotic free			3.0.0	3.0.0	3.0.0
Sample collection and processing	label claim	FOODON:03602001	relates to food processing, allergen information etc.	as described on the label only (e.g. organic, fat-free)	[FOODON:03601063]			12.2.2	12.2.2	12.2.2
, , ,		GENEPIO:0100446	The animal from which the food product was derived.	Provide the common name of the animal. If not applicable, leave blank. Multiple entries can be	t Chicken [NCBITaxon:9031]			3.0.0	3.0.0	3.0.0
Sample collection and processing	animal_source_of_food	GENEFIO.0100440	A production pathway incorporating the processes, material entities (e.g. equipment, animals, locations), and conditions that participate in the	provided, separated by a comma.  Provide the name of the agricultural production	Beef cattle production stream [FOODON:03000452]			3.0.0	3.0.0	3.0.0
Sample collection and processing	food_product_production_stream	GENEPIO:0100699	generation of a food commodity.	stream from the picklist.		production_stream		8.8.7	7.6.4	8.8.7
Sample collection and processing	food_packaging	GENEPIO:0100447	The type of packaging used to contain a food product.  A date recommended for the use	If known, provide information regarding how the food product was packaged.	Plastic tray or pan [FOODON:03490126]			3.0.0	3.0.0	3.0.0
Sample collection and processing	food_quality_date	GENEPIO:0100615		This date is typically labeled on a food product as "best if used by", best by", "use by", or "freeze by" e. 5/24/2020. If the date is known, leave blank or provide a null value.	2020-05-25			6.4.2	6.4.2	6.4.2
Sample collection and processing	food_packaging_date	GENEPIO:0100616	A food product's packaging date as marked by a food manufacturer or retailer.	The packaging date should not be confused with, nor replaced by a Best Before date or other food quality date. If the date is known, leave blank or provide a null value.	2020-05-25			6.4.2	6.4.2	6.4.2
Sample collection and processing	collection_device	GENEPIO:0001234		This field includes animal feed. If applicable, select the standardized term and ontology ID for the anatomical material from the picklist provided. Multiple values can be provided, separated by a semi-colon.	Drag swab [OBI:0002822]			3.0.0	3.0.0	3.0.0
Sample collection and processing	collection method	GENEPIO:0001241	The process used to collect the sample e.g. phlebotomy, necropsy.	If applicable, provide the standardized term and ontology ID for the anatomical material from the picklist provided. Multiple values can be provided, separated by a semi-colon.	Rinsing for specimen collection [GENEPIO_0002116]			3.0.0	3.0.0	3.0.0
Sample collection and processing	sample_volume_measurement_value	GENEPIO:0100768	The numerical value of the volume measurement of the sample collected.	Provide the numerical value of volume.	5			11.1.1	11.1.1	11.1.1
Sample collection and processing	sample_volume_measurement_unit	GENEPIO:0100769	The units of the volume measurement of the sample collected.	Provide the units from the pick list.	milliliter (mL) [UO:0000098]			11.1.1	11.1.1	11.1.1
Sample collection and processing	residual_sample_status	GENEPIO:0101090						11.1.1	11.1.1	11.1.1
Sample collection and processing	sample_storage_method	GENEPIO:0100448	A specification of the way that a specimen is or was stored.	Provide a description of how the same was stored.	Frozen at -20C			3.0.0	3.0.0	3.0.0
Sample collection and processing	sample_storage_medium	GENEPIO:0100449	The material or matrix in which a sample is stored.	Provide a description of the material or matrix used to store the sample.	PBS + 20% glycerol			3.0.0	3.0.0	3.0.0
Sample collection and processing	sample_storage_duration_value	GENEPIO:0101014	The numerical value of the time measurement during which a sample is in storage.	Provide the numerical value of time.	5			11.1.1	11.1.1	11.1.1
Sample collection and processing	sample_storage_duration_unit	GENEPIO:0101015	The units of a measured sample storage duration.	Provide the units from the pick list.	Day [UO:0000033]			11.1.1	11.1.1	11.1.1

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking	10	Di-fi(O-i
	Colour Code Legend							Label	ID	Description/Gu dance
	nucleic_acid_storage_duration_value		The numerical value of the time measurement during which the extracted nucleic acid is in	Provide the numerical value of time.	5	5				
Sample collection and processing		GENEPIO:0101085	storage.					11.1.1	11.1.1	11.1.1
Sample collection and processing	nucleic_acid_storage_duration_unit	GENEPIO:0101086	The units of a measured extracted nucleic acid storage duration.	Provide the units from the pick list.	Year [UO:0000036]			11.1.1	11.1.1	11.1.1
Sample collection and processing	available_data_types	GENEPIO:0100690		This field provides information about additional data types that are available that may provide context for interpretation of the sequence data. Provide a term from the picklist for additional data types that are available. Additional data types may require special permission to access. Contact the data provider for more information.	Total coliform count data			3.0.0	3.0.0	3.0.0
			Detailed information regarding	Use this field to provide free text details describing other available data types that may provide context for interpreting genomic	Pooled metagenomes containing extended spectrum beta-lactamase (ESBL)					
Sample collection and processing	available_data_type_details	GENEPIO:0101023	other available data types.	sequence data.	bacteria			9.0.0	9.0.0	9.0.0
Environmental conditions and measurements										
Environmental conditions and measurements	water_depth	GENEPIO:0100440	The depth of some water.	Provide the numerical depth only of water only (without units).	5			3.0.0	3.0.0	9.0.0
Environmental conditions and measurements	water_depth_units	GENEPIO:0101025	The units of measurement for water depth.	Provide the units of measurement for which the depth was recorded.	m			9.0.0	9.0.0	9.0.0
Environmental conditions and measurements	sediment_depth	GENEPIO:0100697	The depth of some sediment.	Provide the numerical depth only of the sediment (without units).	2			7.6.4	7.6.4	9.0.0
Environmental conditions and measurements	sediment_depth_units	GENEPIO:0101026	The units of measurement for sec	Provide the units of measurement for which the depth was recorded.	m			9.0.0	9.0.0	9.0.0
Environmental conditions and measurements	air_temperature	GENEPIO:0100441	The temperature of some air.	Provide the numerical value for the temperature of the air (without units).	25			3.0.0	3.0.0	9.0.0
Environmental conditions and measurements	air_temperature_units	GENEPIO:0101027	The units of measurement for air temperature.	Provide the units of measurement for which the temperature was recorded.	celsius			9.0.0	9.0.0	9.0.0
Environmental conditions and measurements	water_temperature	GENEPIO:0100698	The temperature of some water.	Provide the numerical value for the temperature of the water (without units).	4			7.6.4	7.6.4	9.0.0
Environmental conditions and measurements	water_temperature_units	GENEPIO:0101028	The units of measurement for water temperature.	Provide the units of measurement for which the temperature was recorded.	celsius			9.0.0	9.0.0	9.0.0
Environmental conditions and measurements	sampling weather conditions	GENEPIO:0100779	The state of the atmosphere at a place and time as regards heat, dryness, sunshine, wind, rain, etc.	Provide the weather conditions at the time of sample collection.	Rain [ENVO:01001564]	weather_type	GENEPIO:0100442	13.3.3	13.3.3	13.3.3
Environmental conditions and			Weather conditions prior to collection that may affect the	Provide the weather conditions prior to sample	Rain [ENVO:01001564]					
measurements  Environmental conditions and	presampling weather conditions	GENEPIO:0100780	sample.  The amount of water which has fallen during a precipitation	collection.  Provide the quantity of precipitation in the area	12	2		13.3.3	13.3.3	13.3.3
measurements	precipitation measurement value	GENEPIO:0100911	process.  The units of measurement for the	leading up to the time of sample collection.	inch			13.3.3	13.3.3	13.3.3
Environmental conditions and measurements	precipitation measurement unit	GENEPIO:0100912	during a precipitation process.	Provide the units of precipitation by selecting a value from the pick list.				13.3.3	13.3.3	13.3.3
Environmental conditions and measurements	precipitation measurement method	GENEPIO:0100913	The process used to measure the amount of water which has fallen during a precipitation process.	Provide the name of the procedure or method used to measure precipitation.	Rain gauge over a 12 hour period prior to sample collection			13.3.3	13.3.3	13.3.3
Host information		GENEPIO:0001268					_			
Host information	host (common name)	GENEPIO:0001386	The commonly used name of the host.	If the sample is directly from a host, either a common or scientific name must be provided (although both can be included, if known). If known, provide the common name.	Cow [NCBITaxon:9913]; Chicken [NCBITaxon:9913], Human [NCBITaxon:9606]			3.0.0	3.0.0	3.0.0
Host information	host (scientific name)	GENEPIO:0001387	The taxonomic, or scientific name of the host.	If the sample is directly from a host, either a common or scientific name must be provided (although both can be included, if known). If known, select the scientific name from the picklist provided.	Bos taurus [NCBITaxon:9913]; Homo sapiens [NCBITaxon:9103]			3.0.0	3.0.0	3.0.0
Host information	host (ecotype)	GENEPIO:0001387	The biotype resulting from selection in a particular habitat, e.g. the A. thaliana Ecotype Ler.	Provide the name of the ecotype of the host	Sea ecotype			3.0.0	3.0.0	3.0.0

						Deprecated Label	Depression ID	Version		
Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Laber	Deprecated ID	Tracking		
	Colour Code Legend							Label	ID	Description/Gui dance
	Social Social Edgine		A breed is a specific group of domestic animals or plants having homogeneous appearance, homogeneous behavior, and other characteristics that distinguish it from other animals or plants of the same species and that were		Holstein					dance
Host information	host (breed)	GENEPIO:0100451	arrived at through selective breeding.	Provide the name of the breed of the host organism.				3.0.0	3.0.0	3.0.0
Host information	host (food production name)	GENEPIO:0100452	The name of the host at a certain stage of food production, which may depend on its age or stage of sexual maturity.	Select the host's food production name from the pick list.	Calf [FOODON:03411349]			3.0.0	3.0.0	3.0.0
Tiost information	nost (rood production name)	GENET 10.0100402	Age of host at the time of	Select the corresponding host age bin from the	First summer			0.0.0	5.0.0	0.0.0
Host information	host_age_bin	GENEPIO:0001394	sampling, expressed as an age group.	pick list provided in the template. If not available, provide a null value or leave blank.	[GENEPIO:0100685]			7.6.4	7.6.4	7.6.4
			The name of the disease	This field is only required if the Pathogen.cl package was selected. If the host was sick, provide the name of the disease. The standardized term can be sourced from this look-up service: https://www.ebi.ac.uk/ols/ontologies/doid if the	mastitis, gastroenteritis					
Host information	host_disease	GENEPIO:0001391	experienced by the host.	disease is not known, put "missing".				3.0.0	3.0.0	3.0.0
Strain and isolation information  Strain and isolation information	microbiological_method	GENEPIO:0100453  GENEPIO:0100454	The laboratory method used to grow, prepare, and/or isolate the microbial isolate.	Provide the name and version number of the microbiological method. The ID of the method is also acceptable if the ID can be linked to the laboratory that created the procedure.				3.0.0	3.0.0	3.0.0
Cetain and isolation information	iniciosiogical_metica	CEREI IO.0100404	moodal solde.	A population or type of organisms that is genetically different from others of the same species and possessing a set of defined characteristics. If the isolate represents or is derived from, a lab reference strain or strain from a type culture collection, provide the	K12			5.0.0	0.0.0	5.6.6
Strain and isolation information	strain	GENEPIO:0100455	The strain identifier.	strain identifier.				3.0.0	3.0.0	3.0.0
Strain and isolation information	isolate_ID	GENEPIO:0100456	Identifier of the specific isolate.	Provide the isolate. ID created by the lab that first isolated the isolate (i.e. the original isolate ID). If the information is unknown or cannot be provided, leave blank or provide a null value. If only an alternate isolate ID is known (e.g. the ID from your lab, if your lab did not isolate the isolate from the original sample), make assure to include it in the alternative_isolate_ID field.	f			3.0.0	3.0.0	3.0.0
			An alternative isolate_ID assigned to the isolate by	Alternative isolate IDs should be provided in the in a prescribed format which consists of the ID followed by square brackets (no space in between the ID and bracket) containing the short form of ID provider's agency name i.e. ID[short organization code]. Agency short forms include the following: Public Health Agency of Canada: PHAC Canadian Food Inspection Agency: CFIA Agriculture and Agri-Food Canada: AFC Fisheries and Oceans Canada: DFC Environment and Climate Change Canada: ECCC Health Canada: HC An example of a properly formatted alternative isolate identifier would be e.g. XY24567(CFIA) Multiple alternative isolate IDs can be	GHIF3456[PHAC]; QWICK222[CFIA]					
Strain and isolation information	alternative_isolate_ID	GENEPIO:0100457	another organization.	provided, separated by semi-colons.				3.0.0	3.0.0	3.0.0
Strain and isolation information	progeny_isolate_ID	GENEPIO:0100458	The identifier assigned to a progenitor isolate derived from ar isolate that was directly obtained from a sample.	If your sequence data pertains to progeny of an original isolate, provide the progeny_isolate_ID.	SUB_ON_1526			3.0.0	3.0.0	3.0.0
Strain and isolation information	IRIDA isolate ID	GENEPIO:0100459	The identifier of the isolate in the IRIDA platform.	Provide the "sample ID" used to track information linked to the isolate in IRIDA. IRIDA sample IDs should be unquie to avoid ID clash. This is very important in large Projects, especially when samples are shared from different organizations. Download the IRIDA sample ID and add it to the sample data in your spreadsheet as part of good data management practices.				3.0.0	3.0.0	3.0.0
			The identifier of the Project in the		666	3				
Strain and isolation information	IRIDA_project_ID	GENEPIO:0100460	iRIDA platform.	Provide the IRIDA "project ID".				3.0.0	3.0.0	3.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking Label	ID	Description/G
	Colour Code Legend							Label	טו	dance
			The name of the agency,	Provide the name of the agency, organization	Public Health Agency of					
			organization or institution with which the individual who	or institution that isolated the original isolate in full (avoid abbreviations). If the information is						
			performed the isolation	unknown or cannot be provided, leave blank or						
Strain and isolation information	isolated_by	GENEPIO:0100461	procedure is affiliated.	provide a null value.				3.0.0	3.0.0	3.0.0
				Provide the name of the specific laboratory that that isolated the original isolate (avoid	Topp Lab					
			The specific laboratory affiliation	abbreviations). If the information is unknown or	r					
Strain and isolation information	isolated by Jaharatany name	GENEPIO:0100462	of the individual who performed the isolation procedure.	cannot be provided, leave blank or provide a null value.				3.0.0	3.0.0	3.0.0
Strain and isolation information	isolated_by_laboratory_name	GENEPIO.0100462	trie isolation procedure.	Provide the name of an individual or their job	Enterice I ah Manager			3.0.0	3.0.0	3.0.0
				title. As personnel turnover may render the	Entonoo Lab Managor					
				contact's name obsolete, it is prefereable to						
			The name or title of the contact	information and institutional memory. If the						
		05115010 0400400	responsible for follow-up	information is unknown or cannot be provided,						
Strain and isolation information	isolated_by_contact_name	GENEPIO:0100463	regarding the isolate.	leave blank or provide a null value.	antarias@lab.es			3.0.0	3.0.0	3.0.0
				Provide the email associated with the listed contact. As personnel turnover may render an	enterics@lab.ca					
				individual's email obsolete, it is more						
				prefereable to provide an address for a position or lab, to ensure accuracy of						
				information and institutional memory. If the						
Strain and isolation information	isolated_by_contact_email	GENEPIO:0100464	responsible for follow-up regarding the isolate.	information is unknown or cannot be provided, leave blank or provide a null value.				3.0.0	3.0.0	3.0.0
Strain and isolation information	isolated_by_contact_email	GENEPIO.0100404	regarding the isolate.	Provide the date according to the ISO 8601	2020-10-30			3.0.0	3.0.0	3.0.0
			The date on which the isolate	standard "YYYY-MM-DD", "YYYY-MM" or	2020-10-00					
Strain and isolation information	isolation_date	GENEPIO:0100465	was isolated from a sample.	"YYYY".				3.0.0	3.0.0	3.0.0
			The date on which the isolate	Provide the date according to the ISO 8601 standard "YYYY-MM-DD", "YYYY-MM" or	2020-11-15					
Strain and isolation information	isolate_received_date	GENEPIO:0100466	was received by the laboratory.	"YYYY".				3.0.0	3.0.0	3.0.0
				Put the genus and species (and subspecies if	Salmonella enterica subsp.					
				applicable) of the bacteria, if known. The standardized term can be sourced from this	enterica [NCBITaxon:59201]					
			Taxonomic name of the	look-up service:						
Strain and isolation information	organism	GENEPIO:0001191	organism.	https://www.ebi.ac.uk/ols/ontologies/ncbitaxon.				3.0.0	3.0.0	3.0.0
				Provide the type of method used to determine	PCR assay [OBI:0002740]					
			The type of planned process by	the taxonomic identity of the organism by selecting a value from the pick list. If the						
			which an organismal entity is	information is unknown or cannot be provided,						
Strain and isolation information	taxonomic_identification_process	GENEPIO:0100583	associated with a taxon or taxa.  The details of the process used	leave blank or provide a null value.	Bill it is			4.2.1	4.2.1	4.2.1
			to determine the taxonomic	Briefly describe the taxonomic identififcation	Biolog instrument					
Strain and isolation information	taxonomic_identification_process_details	GENEPIO:0100584	identification of an organism.	method details using free text.				4.2.1	4.2.1	4.2.1
				Only include this information if it has been	Heidelberg					
				determined by traditional serological methods or a validated in silico prediction tool e.g.						
Strain and isolation information	serovar	GENEPIO:0100467	The serovar of the organism.	SISTR.				3.0.0	3.0.0	3.0.0
				If the serovar was determined via traditional	SISTR 1.0.1					
				serotyping methods, put "Traditional serotyping". If the serovar was determined via						
			The method used to determine	in silico methods, provide the name and						
Strain and isolation information	serotyping_method	GENEPIO:0100468	the serovar.	version number of the software.				3.0.0	3.0.0	3.0.0
Strain and isolation information Sequence information	phagetype	GENEPIO:0100469 GENEPIO:0001441	The phagetype of the organism.	Provide if known. If unknown, put "missing".	47			3.0.0	3.0.0	3.0.0
sequence information		GENEPIO:0001441		From Hibrary ID! from a single submitter must	LC 2010 ND 122446					
				Every "library ID" from a single submitter must be unique. It can have any format, but we	L3_2010_NP_123440					
			The user-specified identifier for	suggest that you make it concise, unique and						
Sequence information	library_ID	GENEPIO:0001448	the library prepared for sequencing.	consistent within your lab, and as informative as possible.				3.0.0	3.0.0	3.0.0
				Provide the name of the agency, organization	Public Health Agency of					
			The name of the agency, organization or institution	or institution that performed the sequencing in full (avoid abbreviations). If the information is	Canada (PHAC) [GENEPIO:0100551]					
			responsible for sequencing the	unknown or cannot be provided, leave blank of						
Sequence information	sequenced_by	GENEPIO:0100416	isolate's genome.	provide a null value.				3.0.0	3.0.0	3.0.0
				Provide the name of the specific laboratory	Topp Lab					
			The specific laboratory affiliation	that that performed the sequencing in full (avoid abbreviations). If the information is						
			of the responsible for sequencing	unknown or cannot be provided, leave blank or	r					
Sequence information	sequenced_by_laboratory_name	GENEPIO:0100470	the isolate's genome.	provide a null value.				3.0.0	3.0.0	3.0.0
				Provide the name of an individual or their job title. As personnel turnover may render the	Enterics Lab Manager					
				contact's name obsolete, it is more prefereable						
			The name or title - f the	to provide a job title for ensuring accuracy of						
			The name or title of the contact responsible for follow-up	information and institutional memory. If the information is unknown or cannot be provided,						
Sequence information	sequenced by contact name	GENEPIO:0100471	regarding the sequence.	leave blank or provide a null value.				3.0.0	3.0.0	3.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking Label	ID	Description/Gu
Sequence information	Colour Code Legend  sequenced_by_contact_email	GENEPIO:0100422	The email address of the contact responsible for follow-up regarding the sequence.	Provide the email associated with the listed contact. As personnel turnover may render an individual's email obsolete, it is more prefereable to provide an address for a position or lab, to ensure accuracy of information and institutional memory. If the information is unknown or cannot be provided, leave blank or provide a null Value.	enterics@lab.ca			3.0.0	3.0.0	dance 3.0.0
Sequence information	purpose_of_sequencing	GENEPIO:0001445	The reason that the sample was sequenced.	Provide the reason for sequencing by setcling a value from the following pick list: Diagnostic testing, Surveillance, Monitoring, Clinical trial, Field experiment, Environmental testing. If the information is unknown or canno be provided, leave blank or provide a null value.	Research [GENEPIO:0100003]			3.0.0	3.0.0	3.0.0
Sequence information	sequencing_date	GENEPIO:0001447	The date the sample or isolate was sequenced.	ISO 8601 standard "YYYY-MM-DD".	2020-06-22			14.5.4	14.5.4	14.5.4
Sequence information	sequencing_project_name	GENEPIO:0100472	The name of the project/initiative/program for which sequencing was performed.	Provide the name of the project and/or the project ID here. If the information is unknown or cannot be provided, leave blank or provide a null value.	AMR-GRDI (PA-1356)			3.0.0	3.0.0	3.0.0
Sequence information	sequencing_platform	GENEPIO:0100473	The platform technology used to perform the sequencing.	Provide the name of the company that created the sequencing instrument by selecting a value from the template pick list. If the information is unknown or cannot be provided, leave blank or provide a null value.				3.0.0	3.0.0	3.0.0
Sequence information	sequencing_instrument	GENEPIO:0001452	The model of the sequencing instrument used.	Provide the model sequencing instrument by selecting a value from the template pick list. If the information is unknown or cannot be provided, leave blank or provide a null value.	Illumina HiSeq 2500 [GENEPIO:0100117]			3.0.0	3.0.0	3.0.0
Sequence information	sequencing_assay_type	GENEPIO:0100997	The overarching sequencing methodology that was used to determine the sequence of a biomaterial.	Example Guidance: Provide the name of the DNA or RNA sequencing technology used in your study. If unsure refer to the protocol documentation, or provide a null value.	whole genome sequencing assay [OBI:0002117]			10.0.0	10.0.0	10.0.0
Sequence information	library_preparation_kit	GENEPIO:0001450	The name of the DNA library preparation kit used to generate the library being sequenced.	Provide the name of the library preparation kit used.	Nextera XT			3.0.0	3.0.0	3.0.0
Sequence information	DNA fragment length	GENEPIO:0100843	The length of the DNA fragment generated by mechanical shearing or enzymatic digestion for the purposes of library preparation.	Provide the fragment length in base pairs (do not include the units).	400			11.1.1	11.1.1	11.1.1
Comment in farmantian		GENEPIO:0100966	selectively capture and amplify specific regions of interest from a	Provide the name of the enrichment method	Hybrid selection method (bait-capture) [GENEPIO:0001950]			444	44.4	11.1.1
Sequence information  Sequence information	genomic target enrichment method  genomic target enrichment method details	GENEPIO:0100967	genome.  Details that provide additional context to the molecular technique used to selectively capture and amplify specific regions of interest from a genome.	Provide details that are applicable to the method you used. Note: If ball-capture methods were used for enrichment, provide the panel name and version number (or a URL providing that information).	enrichment was done using Twist's respiratory virus research panel: https://www.twistbioscience.co m/products/ings/fixed-panels/re spiratory-virus-research-panel			11.1.1	11.1.1	11.1.1
		GENEPIO:0001456	(primer sequences, binding positions, fragment size generated etc) used to generate	Provide the name and version of the primer scheme used to generate the amplicons for sequencing.	artic v3					
Sequence information	amplicon pcr primer scheme	GENEPIO:0001449	The length of the amplicon	Provide the amplicon size expressed in base	300	)		11.1.1	11.1.1	11.1.1
Sequence information	amplicon size	GENEPIO:0101102	generated by PCR amplification. The version number of the flow cell used for generating sequence data.	pairs. Flow cells can vary in terms of design, chemistry, capacity, etc. The version of the flow cell used to generate sequence data can affect sequence quantity and quality. Record the version of the flow cell used to generate sequence data. Do not include "version" or "v"	R.9.4.1			11.1.1	11.1.1	11.1.1
Sequence information	sequencing flow cell version			in the version number.  Provide the name and version of the	https://www.protocols.io/view/n		GENEPIO:0101084	11.1.1	11.1.1	11.1.1
Sequence information	sequencing_protocol	GENEPIO:0001454	The protocol or method used for sequencing.	procedure or protocol used for sequencing. You can also provide a link to a protocol online.	cov-2019-sequencing-protocol- bbmuik6w?version_warning=n o	:		3.0.0	3.0.0	3.0.0
Sequence information	r1_fastq_filename	GENEPIO:0001476	The user-specified filename of the r1 FASTQ file.	Provide the r1 FASTQ filename.	ABC123_S1_L001_R1_001.fa stq.gz			3.0.0	3.0.0	3.0.0
Sequence information	r2_fastq_filename	GENEPIO:0001477	The user-specified filename of the r2 FASTQ file.	Provide the r2 FASTQ filename.	ABC123_S1_L001_R2_001.fa stq.gz			3.0.0	3.0.0	3.0.0
Sequence information	fast5_filename	GENEPIO:0001480	The user-specified filename of the FAST5 file.	Provide the FAST5 filename.	batch1a_sequences.fast5			3.0.0	3.0.0	3.0.0
Sequence information Bioinformatics and QC metrics	genome_sequence_filename	GENEPIO:0101715 GENEPIO:0001457	The user-defined filename of the FASTA file.	Provide the FASTA filename.	pathogenassembly123.fasta	assembly_filename	GENEPIO:0001461	13.4.4	13.4.4	3.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking Label	ID	Description/Gu
	Colour Code Legend			Providing the name of the method used for				Eddor		dance
			The name of the method used to	quality control is very important for interpreting the rest of the QC information. Method names can be provided as the name of a pipeline or a link to a GitHub repository. Multiple methods						
Bioinformatics and QC metrics	quality control method name	GENEPIO:0100557	assess whether a sequence passed a predetermined quality control threshold.	should be listed and separated by a semi-colon. Do not include QC tags in other fields if no method name is provided.	ncov-tools			11.1.1	11.1.1	11.1.1
			The version number of the method used to assess whether a sequence passed a predetermined quality control	Methods updates can make big differences to their outputs. Provide the version of the method used for quality control. The version can be expressed using whatever convention the developer implements (e.g. date, semantic versioning). If multiple methods were used, record the version numbers in the same order as the method names. Separate the version						
Bioinformatics and QC metrics	quality control method version	GENEPIO:0100558	threshold.	numbers using a semi-colon.  Select a value from the pick list provided. If a desired value is missing, submit a new term	1.2.3			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	quality control determination	GENEPIO:0100559	The determination of a quality control assessment.	request to the PHA4GE QC Tag GitHub issuetracker using the New Term Request form.	sequence failed quality control			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics		GENEPIO:0100560	The reason contributing to, or causing, a low quality determination in a quality control assessment.	Select a value from the pick list provided. If a desired value is missing, submit a new term request to the PHA4GE QC Tag GitHub				11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	quality control issues  quality control details	GENEPIO:0100560	The details surrounding a low quality determination in a quality control assessment.		low average genome coverage CT value of 39. Low viral load. Low DNA concentration after amplification.			11.1.1	11.1.1	11.1.1
			The method used for raw data processing such as removing barcodes, adapter trimming,	Raw data processing can have a significant impact on data quality and how it can be used. Provide the names and version numbers of software used for trimming adaptors, quality filtering, etc (e.g. Trimmomatte v. 0.38, Porechop v. 0.2.3), or a link to a GitHub	·					
Bioinformatics and QC metrics	raw sequence data processing method	GENEPIO:0001458	filtering etc.  The method used to remove host reads from the pathogen	protocol.  Provide the name and version number of the	Porechop 0.2.3			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	dehosting method	GENEPIO:0001459	sequence.	software used to remove host reads.  Provide the name of the software used to	Nanostripper SPAdes Genome Assembler,			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	sequence assembly software name	GENEPIO:0100825	assemble a sequence.	assemble the sequence.  Provide the version of the software used to	Canu, wtdbg2, velvet			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	sequence assembly software version	GENEPIO:0100826	to assemble a sequence.  The name of the software used to	assemble the sequence.	3.15.5			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	consensus sequence software name	GENEPIO:0001463	generate the consensus sequence.  The version of the software used	Provide the name of the software used to generate the consensus sequence.	iVar			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	consensus sequence software version	GENEPIO:0001469	to generate the consensus sequence.	Provide the version of the software used to generate the consensus sequence.	1.3	3		11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	breadth of coverage value	GENEPIO:0001472	The percentage of the reference genome covered by the sequenced data, to a prescribed depth.	Provide value as a percent.	96	5		11.1.1	11.1.1	11.1.1
		OENEDIO 0004474	The average number of reads representing a given nucleotide							
Bioinformatics and QC metrics	depth of coverage value	GENEPIO:0001474  GENEPIO:0001475	in the reconstructed sequence.  The threshold used as a cut-off	Provide value as a fold of coverage.	400			11.1.1	11.1.1	11.1.1
bioinformatics and QC metrics	depth of coverage threshold	GENEFIO.0001475	for the depth of coverage.  The percentage of expected genes identified in the genome being sequenced. Missing genes indicate missing genomic regions	Provide the threshold fold coverage.  Provide the genome completeness as a	100	,		11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	genome completeness	GENEPIO:0100844	(incompleteness) in the data.  The number of total base pairs generated by the sequencing	percent (no need to include units).  Provide a numerical value (no need to include	85	3		11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	number of base pairs sequenced	GENEPIO:0001482	process.  The total number of non-unique reads generated by the	units).  Provide a numerical value (no need to include	387566	3		11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	number of total reads	GENEPIO:0100827	sequencing process.  The number of unique reads	units).	423867	,		11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	number of unique reads	GENEPIO:0100828	generated by the sequencing process.	Provide a numerical value (no need to include units).	248236	3		11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	minimum post-trimming read length	GENEPIO:0100829	after trimming.	Provide a numerical value (no need to include units).	150			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	number of contigs	GENEPIO:0100937	The number of contigs (contiguous sequences) in a sequence assembly.	Provide a numerical value.	10			11.1.1	11.1.1	11.1.1

3/4/2025

9

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label I	Deprecated ID	Version Tracking		
	Colour Code Legend							Label	ID	Description/Gu dance
			The percentage of the assembly							
Bioinformatics and QC metrics	percent Ns across total genome length	GENEPIO:0100830	that consists of ambiguous bases (Ns).	Provide a numerical value (no need to include units).				11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	Ns per 100 kbp	GENEPIO:0001484	The number of ambiguous bases (Ns) normalized per 100 kilobasepairs (kbp).	Provide a numerical value (no need to include units).	345			11.1.1	11.1.1	11.1.1
Something and QC mounts	The post foot hop	GENERIO: SOSTION	The length of the shortest read that, together with other reads, represents at least 50% of the							
Bioinformatics and QC metrics	N50	GENEPIO:0100938	nucleotides in a set of sequences.	Provide the N50 value in Mb.	150			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	percent read contamination	GENEPIO:0100845	The percent of the total number of reads identified as contamination (not belonging to the target organism) in a sequence dataset.	Provide the percent contamination value (no need to include units).				11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	sequence assembly length	GENEPIO:0100846	The length of the genome generated by assembling reads using a scaffold or by reference-based mapping.	Provide a numerical value (no need to include units).	34272			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	consensus genome length	GENEPIO:0001483	The length of the genome defined by the most common nucleotides at each position.	Provide a numerical value (no need to include units).	38677			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	reference genome accession	GENEPIO:0001485	genome database entry.	Provide the accession number of the reference genome.	NC_045512.2			11.1.1	11.1.1	11.1.1
Bioinformatics and QC metrics	deduplication method	GENEPIO:0100831	The method used to remove duplicated reads in a sequence read dataset.	Provide the deduplication software name followed by the version, or a link to a tool or method.	DeDup 0.12.8			11.1.1	11.1.1	11.1.1
			A description of the overall	Further details regarding the methods used to process raw data, and/or generate assemblies, and/or generate consensus sequences can. This information can be provided in an SOP or protocol or pipeline/workflow. Provide the name and version number of the protocol, or a GifHub	https://github.com/phac-nml/nc					
Bioinformatics and QC metrics  Taxonomic identification	bioinformatics protocol	GENEPIO:0001489	bioinformatics strategy used.	link to a pipeline or workflow.	ov2019-artic-nf			11.1.1	11.1.1	11.1.1
information		GENEPIO:0101082								
			The name of the software used to map sequence reads to a reference genome or set of	Provide the name of the read mapping						
Taxonomic identification information	read mapping software name	GENEPIO:0100832	reference genes.  The version of the software used to map sequence reads to a	software.	Bowtie2, BWA-MEM, TopHat			11.1.1	11.1.1	11.1.1
Taxonomic identification information	read mapping software version	GENEPIO:0100833	reference genome or set of reference genes.  The name of the taxonomic	Provide the version number of the read mapping software.	2.5.1			11.1.1	11.1.1	11.1.1
Taxonomic identification information	taxonomic reference database name	GENEPIO:0100834	reference database used to identify the organism.	Provide the name of the taxonomic reference database.	NCBITaxon			11.1.1	11.1.1	11.1.1
Taxonomic identification information	taxonomic reference database version	GENEPIO:0100835	The version of the taxonomic reference database used to identify the organism.	Provide the version number of the taxonomic reference database.	1.3			11.1.1	11.1.1	11.1.1
Taxonomic identification information	taxonomic analysis report filename	GENEPIO:0101074	The filename of the report containing the results of a taxonomic analysis.	Provide the filename of the report containing the results of the taxonomic analysis.	WWtax_report_Feb1_2024.do			11.1.1	11.1.1	11.1.1
			The date a taxonomic analysis	Providing the date that an analyis was performed can help provide context for tool and reference database versions. Provide the date that the taxonomic analysis was performed in ISO 8601 format, i.e.						
Taxonomic identification information	taxonomic analysis date	GENEPIO:0101075	was performed.  A description of the criteria used	"YYYY-MM-DD".	2024-02-01			11.1.1	11.1.1	11.1.1
Taxonomic identification information	read mapping criteria	GENEPIO:0100836	A description of the criteria used to map reads to a reference sequence.	Provide a description of the read mapping criteria.	Phred score >20			11.1.1	11.1.1	11.1.1
Public repository information		GENEPIO:0100477	The name of the agency that submitted the sequence to a	The name of the agency should be written out in full, (with minor exceptions) and be consistent across multiple submissions. If submitting specimens rather than sequencing data, please put the "National Microbiology	Change Canada (EC) [GENEPIO:0100555]			200	200	206
Public repository information	sequence_submitted_by	GENEPIO:0001159	database.	Laboratory (NML)".  Provide the name of an individual or their job				3.0.0	3.0.0	3.0.0
· ,			The name or title of the contact responsible for follow-up regarding the submission of the sequence to a repository or	title. As personnel turnover may render the contact's name obsolete, it is prefereable to provide a job title for ensuring accuracy of information and institutional memory. If the information is unknown or cannot be provided,						

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking	ID	Docovintion (C
	Colour Code Legend							Label	טו	Description/Gu dance
				The email address can represent a specific	RespLab@lab.ca					
ublic repository information	sequence_submitted_by_contact_email	GENEPIO:0001165	responsible for submission of the sequence.	individual or lab e.g. johnnyblogs@lab.ca, or RespLab@lab.ca				3.0.0	3.0.0	3.0.0
. ,				If the isolate is associated with a published	PMID: 33205991					
				work which can provide additional information, provide the PubMed identifier of the						
h.h.li	authliantian ID	OENEDIO 0400475		publication. Other types of identifiers (e.g.				200	0.00	200
ublic repository information	publication_ID	GENEPIO:0100475	The identifier for a publication.	DOI) are also acceptable.  If the sample is from a specific human or	Pathogen.env			3.0.0	3.0.0	3.0.0
				animal, put "Pathogen.cl". If the sample is from	ı Ö					
			The attribute package used to structure metadata in an INSDC	an environmental sample including food, feed, production facility, farm, water source, manure						
ublic repository information	attribute_package	GENEPIO:0100476	BioSample.	etc, put "Pathogen.env".				3.0.0	3.0.0	3.0.0
				Required if submission is linked to a BioProject. BioProjects are an organizing tool	PRJNA12345					
				that links together raw sequence data, assemblies, and their associated metadata. A						
				valid BioProject accession has prefix PRJN,						
			The INSDC accession number of	PRJE or PRJD, e.g., PRJNA12345 and is created once at the beginning of a new						
		05115010 0001100	the BioProject(s) to which the	sequencing project. Your laboratory can have						
ublic repository information	bioproject_accession	GENEPIO:0001136	BioSample belongs.	one or many BioProjects.  Store the accession returned from the	SAMN14180202			3.0.0	3.0.0	3.0.0
			The idealification and to	BioSample submission. NCBI BioSamples will						
ublic repository information	biosample_accession	GENEPIO:0001139	The identifier assigned to a BioSample in INSDC archives.	have the prefix SAMN, whileEMBL- EBI BioSamples will have the prefix SAMEA.				3.0.0	3.0.0	3.0.0
. ,	· -		The Sequence Read Archive		SRR11177792					
			(SRA), European Nucleotide Archive (ENA) or DDBJ							
			Sequence Read Archive (DRA) identifier linking raw read data,	Store the accession assigned to the submitted						
			methodological metadata and	"run". NCBI-SRA accessions start with SRR,						
ublic repository information	SRA_accession	GENEPIO:0001142	quality control metrics submitted to the INSDC.	EBI-ENA runs start with ERR and DRA accessions start with DRR.				3.0.0	3.0.0	3.0.0
abile repository information	5.0.C_000000000	02112710.0001112	The GenBank/ENA/DDBJ	dococoonic start war brat.	MN908947.3			0.0.0	0.0.0	0.0.0
ublic repository information	GenBank_accession	GENEPIO:0001145	identifier assigned to the sequence in the INSDC archives.	Store the accession returned from a GenBank/ENA/DDBJ submission.				3.0.0	3.0.0	3.0.0
isk assessment information	Gendank_accession	GENEPIO:0100478	sequence in the involve archives.	GCHBAHVEIVVBBB SUBHISSION.				0.0.0	0.0.0	5.0.0
				Risk assessment requires detailed information	Number of total samples					
				regarding the quantities of a pathogen in a specified location, commodity, or environment.	collected, Number of positive samples					
				As such, it is useful for risk assessors to know what types of information are available through						
				documented methods and results. Provide the						
				metric types that are available in the surveillance project sample plan by selecting						
				them from the pick list. The metrics of interest						
				are " Number of total samples collected", "Number of positive samples", "Average count						
			Metrics regarding the prevalence of the pathogen of interest	of hazard organism", "Average count of indicator organism". You do not need to						
			obtained from a surveillance	provide the actual values, just indicate that the	•					
isk assessment information	prevalence_metrics	GENEPIO:0100480	project. The details pertaining to the	information is available.  If there are details pertaining to samples or	Hazard organism counts (i.e.			3.0.0	3.0.0	3.0.0
			prevalence metrics from a	organism counts in the sample plan that might	Salmonella) do not distinguish					
sk assessment information	prevalence_metrics_details	GENEPIO:0100481	surveillance project.	be informative, provide details using free text.  Provide the stage of food production as free	between serovars. Abattoir			3.0.0	3.0.0	3.0.0
sk assessment information	stage_of_production	GENEPIO:0100482	The stage of food production.	text.	rivattuii			3.0.0	3.0.0	3.0.0
				In some surveys, a particular intervention in	Vaccination [NCIT:C15346]					
				the food supply chain in studied. If there was an intervention specified in the sample plan,						
isk assessment information	experimental_intervention	GENEPIO:0100483	intervention applied in the food production system.	select the intervention category from the pick				3.0.0	3.0.0	3.0.0
somont mornaudii			The details of the experimental	If an experimental intervention was applied in	2% cranberry solution mixed in			2.0.0	3.0.0	3.0.0
isk assessment information	experiment intervention details	GENEPIO:0100484	intervention applied in the food production system.	the survey, provide details in this field as free text.	feed			3.0.0	3.0.0	3.0.0
ntimicrobial resistance		GENEPIO:0100479	p	1				5.0.0	3.0.0	3.0.0
			The server of the	The names of the drug have already been	Amoxicillin-clavulanic					
			The name of the agent that kills or slows the growth of	matched with measurement, breakpoint, and phenotype fields in the template. No need to	[ARO:3003997]					
			microorganisms, including	add these unless the drug of interest is not present. Use the Term Request System to						
ntimicrobial resistance	antimicrobial_agent_name	GENEPIO:0100521	protozoans.	request the addition of other agents.				3.0.0	3.0.0	3.0.0
				Provide the name of the agency, organization or institution that performed the AMR testing						
			The name of the organization	in full (avoid abbreviations). If the information	Agency (CFIA) [GENEPIO:0100552]					
ntimicrobial resistance	AMR_testing_by	GENEPIO:0100511		is unknown or cannot be provided, leave blank or provide a null value.				3.0.0	3.0.0	3.0.0
anno obiai rosistatio	runt_tosting_by	OLI4LI 10.0100011	rosistance testing.	or provide a null value.				0.0.0	0.0.0	0.0.0

Parent Class	Field	Ontology Identifier	Definition	Guidance	Examples	Deprecated Label	Deprecated ID	Version Tracking	ID.	Description
	Colour Code Legend							Label	ID	Description/Gu dance
Antimicrobial resistance	AMR_testing_by_laboratory_name	GENEPIO:0100512	The name of the lab within the organization that performed the antimicrobial resistance testing.	Provide the name of the specific laboratory that performed the AMR testing (avoid abbreviations). If the information is unknown o cannot be provided, leave blank or provide a null value.	Topp Lab			3.0.0	3.0.0	3.0.0
Antimicrobial resistance  Antimicrobial resistance	AMR_testing_by_contact_name	GENEPIO:0100512	The name of the individual or the individual's role in the organization that performed the antimicrobial resistance testing.	Provide the name of an individual or their job title. As personnel turnover may render the contact's name obsolete, it is more preferable	Enterics Lab Manager			3.0.0	3.0.0	3.0.0
			The email of the individual or the individual's role in the organization that performed the	Provide the email associated with the listed contact. As personnel turnover may render an individual's email obsolete, it is more preferable to provide an address for a position or lab, to ensure accuracy of information and institutional memory. If the information is unknown or cannot be provided, leave blank o						
Antimicrobial resistance	AMR_testing_by_contact_email	GENEPIO:0100514	antimicrobial resistance testing.  The date the antimicrobial	provide a null value.  Provide the date according to the ISO 8601	2022-04-03			3.0.0	3.0.0	3.0.0
Antimicrobial resistance	AMR_testing_date	GENEPIO:0100515	resistance testing was performed.	standard "YYYY-MM-DD", "YYYY-MM" or "YYYY".				3.0.0	3.0.0	3.0.0
Antimicrobial resistance	antimicrobial_resistance_phenotype		The antimicrobial resistance phenotype, as determined by the antibiotic susceptibility measurement and testing standard for this antibiotic	Select a phenotype from the pick list provided.	Susceptible antimicrobial phenotype [ARO:3004302]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_measurement		The measured value of antimicrobial resistance.	This field should only contain a number (either an integer or a number with decimals).	- 4			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_measurement_units		The units of the antimicrobial resistance measurement.	Select the units from the pick list provided. Use the Term Request System to request the addition of other units if necessary.	ug/mL [UO:0000274]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial measurement sign		The qualifier associated with the antibiotic susceptibility measurement	Select the comparator sign from the pick list provided. Use the Term Request System to request the addition of other signs if necessary.	greater than (>) [GENEPIO:0001006]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_laboratory_typing_method		The general method used for antibiotic susceptibility testing.	Select a typing method from the pick list provided. Use the Term Request System to request the addition of other methods if necessary.	Broth dilution [ARO:3004397]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_laboratory_typing_platform		The brand/platform used for antibiotic susceptibility testing	Select a typing platform from the pick list provided. Use the Term Request System to request the addition of other platforms if necessary.	Sensitire [ARO:3004402]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_laboratory_typing_platform_version		The specific name and version of		CMV3AGNF			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_vendor_name		The name of the vendor of the testing platform used.	Provide the full name of the company (avoid abbreviations).	Sensititre [ARO:3004402]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_testing_standard		The testing standard used for determination of resistance phenotype	Select a testing standard from the pick list provided.	Clinical Laboratory and Standards Institute (CLSI) [ARO:3004366]			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_testing_standard_version		The version number associated with the testing standard used for determination of resistance phenotype	. If applicable, include a version number for the testing standard used.	M100			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial testing standard details		The additional details associated with the testing standard used for determination of resistance phenotype	This information may include the year or location where the testing standard was published. If not applicable, leave blank.	27th ed. Wayne, PA: Clinical and Laboratory Standards Institute; 2017.			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_susceptible_breakpoint		The maximum measurement, in the units specified in the	This field should only contain a number (either an integer or a number with decimals), since the "<=" qualifier is implied.				7.7.5		3.0.0
Antimicrobial resistance	antimicrobial intermediate breakpoint		The intermediate measurement(s), in the units specified in the "AMR_measurement_units" field, where a sample would be considered to have an "intermediate" phenotype for this antibiotic		16			7.7.5		3.0.0
Antimicrobial resistance	antimicrobial_resistant_breakpoint		The minimum measurement, in the units specified in the	This field should only contain a number (either an integer or a number with decimals), since the ">=" qualifier is implied.	32			7.7.5		3.0.0